



OWNER'S MANUAL



D U F O U R 3 8 5

Your dealer

Name

is **DUFOUR YACHTS'** representative and will give you all the help you need to solve any problems you might have during launching, stepping the mast or with technical checks for bringing your boat into service and maintaining it. If necessary, he will help you with the administrative process of registering your boat.

As soon as you become the owner, familiarize yourself with the manual supplied with your boat, sign and date the receipt acknowledgements below, and give (or send) the last one to your agent.

Owner's Manual Receipt Acknowledgement to be kept in your Manual

I, the undersigned :

Name :

Address

Owner of **DUFOUR 385** no.

Confirm that I have received the **DUFOUR 385 Owner's Manual** and accept its being written in the French language.

Date :

Signature :

Detach along dotted line

Owner's Manual Receipt Acknowledgement to be returned to DUFOUR YACHTS

Z.I.- 1, Rue Blaise Pascal- 17187 PERIGNY CEDEX- FRANCE

I, the undersigned :

Name :

Address :

Owner of **DUFOUR 385** no:

Confirm that I have received the **DUFOUR 385 Owner's Manual** and accept its being written in the French language.

Date:

Signature :

CONTENTS

| | |
|--|-----------|
| INTRODUCTION | 5 |
| I. GENERAL INFORMATION | 6 |
| A. Design category of the yacht | 6 |
| B. Certification | 6 |
| C. Identification | 6 |
| D. Builder plate | 7 |
| II. MAIN CHARACTERISTICS | 8 |
| III. ELECTRICAL SYSTEMS | 9 |
| A. Safety and operating instructions for the electrical system | 9 |
| B. Installing new equipment | 9 |
| C. Batteries | 10 |
| D. Electric winch | 10 |
| E. 220/110 Volt installation | 10 |
| IV. GAS INSTALLATION | 12 |
| A. Operation advice | 12 |
| B. Checking the system | 13 |
| C. Changing the gas cylinder | 13 |
| V. DRAIN AND SANITATION SYSTEM | 14 |
| A. Specifications of the drain system | 14 |
| B. Pressurised fresh water pump | 14 |
| C. Seacocks | 15 |
| D. Operating the sea toilets | 15 |
| VI. FLOODING | 16 |
| VII. FIRE PROTECTION | 16 |
| A. Installation | 16 |
| B. Safety instructions | 17 |
| VIII. ENGINE | 18 |
| A. General precautions | 18 |
| B. Exhaust gas emission | 18 |
| C. Safety | 18 |
| D. Winterisation | 19 |
| IX. FUEL INSTALLATION | 19 |
| X. STEERING SYSTEM | 19 |
| A. Steering wheels | 19 |
| B. Emergency tiller | 20 |
| XI. SAILING | 20 |
| XII. LIGHTNING PROTECTION | 21 |
| A. Maintenance | 21 |
| B. Protection of people during thunderstorm | 21 |
| XIII. ENVIRONMENTAL PROTECTION and SAFETY | 21 |
| XIV. SAFETY EQUIPMENT | 22 |
| XV. HANDLING, TRANSPORTING, LIFT OUT | 23 |

| | |
|---|----|
| <i>I. Presentation plan</i> | 26 |
| <i>II. Interior layout plans</i> | 27 |
| <i>III. Deck fittings plan</i> | 28 |
| <i>IV. Sail plan</i> | 30 |
| <i>V. Halyard and sheet rigging plan</i> | 32 |
| <i>VI. 110 V circuit diagram</i> | 34 |
| <i>VII. 220 V circuit diagram</i> | 36 |
| <i>VIII. Charging and power circuit diagram</i> | 38 |
| <i>IX. 12v / 220 v electric switch panel diagram</i> | 40 |
| <i>X. Electric panel terminal diagram</i> | 42 |
| <i>XI. 12 V installation drawing</i> | 44 |
| <i>XII. 220 V installation drawing</i> | 46 |
| <i>XIII. Steering wheel drawing</i> | 48 |
| <i>XIV. Gas circuit diagram</i> | 50 |
| <i>XV. Abandon ship plan</i> | 52 |
| <i>XVI. Fresh water circuit diagram</i> | 54 |
| <i>XVII. Drain system diagram</i> | 56 |
| <i>XVIII. Skin fitting location drawing</i> | 58 |
| <i>XIX. Engine installation drawing</i> | 60 |
| <i>XX. Holding tank fitting drawing</i> | 62 |
| <i>XXI. Holding tank fitting drawing in 3 cabin version</i> | 64 |

INTRODUCTION

DUFOUR YACHTS is delighted to present you with this manual that will enable you to get to know your boat better.

This manual has been produced to help you enjoy the use of your boat in complete safety. Read it carefully, in particular to avoid fire and flooding risks, and familiarize yourself with your boat before using it.

If this is your first boat, or if you are changing to a type of boat you are unfamiliar with, for your convenience and safety, make sure you gain experience in handling and use before taking command of your boat. Your dealer, your national yachting federation or your yacht club will be more than happy to recommend local sailing schools or qualified instructors.

KEEP THIS MANUAL IN A SAFE PLACE AND PASS IT ON TO THE NEW OWNER IF YOU SELL YOUR BOAT.

NOTICE:

Our boats are regularly improved in the light of our customers' experiences and research by the shipyard, and so the specifications given in this Owner's Manual are not contractually binding and may be changed without notice and without any obligation to update.

This manual is intended to cover as much information as possible, so certain equipment or paragraphs might not apply to your boat. In case of doubt, please refer to the inventory which should have been given to you by your agent when you placed your order.

I. GENERAL INFORMATION

A. DESIGN CATEGORY OF THE YACHT

Your **DUFOUR 385** comes under the OCEAN-GOING design category (category A). In normal conditions of use, your boat is designed for sailing with effective wave heights up to 4 m and winds of Beaufort Force 8 or less, and to withstand the severest conditions.

This sailing capability is equally dependent on the skills of the crew, their physical capacities, the maintenance of the boat and its equipment.

So always take care before putting to sea.

DUFOUR YACHTS is not able to guarantee perfect functioning of the boat in exceptional sea conditions (violent storms, hurricanes, cyclones, waterspouts,...)

DESIGN CATEGORIES

| Design category | Type of sailing | Wind strength (Beaufort) | Wind Speed | Effective height of wave to be taken into account |
|-----------------|------------------|--------------------------|------------------|---|
| A | Ocean-going | More than 8 | More than 21 m/s | More than 4 m |
| B | Open sea | Up to and including 8 | Up to 21 m/s | Up to and including 4 m |
| C | Inshore | Up to and including 6 | Up to 17 m/s | Up to and including 2 m |
| D | Sheltered waters | Up to and including 4 | Up to 13 m/s | Up to and including 0.3 m |

B. CERTIFICATION


CE regulations impose all boat hulls longer than 12m to comply with category A bis (=auto-certification, stability and floating capacity to be evaluated by a recognised institution).

It is the **IMCI** (International Marine Certification Institute) who has been charged to carry out this certification (see Document of Conformity = Déclaration de Conformité)

C. IDENTIFICATION

The hull's identification number is situated on the hull, at starboard side, close to the stern. The number is composed of a series of characters and numbers starting with FR-DUF....

D. BUILDER PLATE



The builder plate is situated in the cockpit.
It explains some essential information in which you find details below.

Design Category = **A** : Ocean going (see 1.1)

Max. number of persons on board = **8** : recommended by the yard when the boat is navigating under conditions in accordance with its design category



Max. added load = **908 kg** : including 8 persons, equipment, personal belongings and supplies (excluding the capacity of various tanks (water, fuel,...))



CE 0609 : CE certification number confirms that the boat complies with all CE regulations. The number indicates the code of the Certification organisation, in this case, the IMCI (International Marine Certification Institute) in Brussels, (see : Document of conformity = Déclaration de conformité)

II. MAIN CHARACTERISTICS

| | |
|---|----------------------|
| Model | DUFOUR 385 |
| Architect: | Umberto Felci |
| Navigation category | A |
| CE certification number | CE/0609 |
| Length over all | 11.72 m |
| Hull length | 11.36 m |
| Waterline length | 9.84 m |
| Maximum width | 3.93 m |
| Draft | 1.76 m |
| Air draft | 16.20 m |
| Ballast weight | 1950 kg |
| Empty weight (incl. Safety equipment) | 6980 kg |
| Full load | 8460 kg |
| Standard mainsail surface (approx.) | 31.50 m ² |
| Surface furling genoa (approx.) | 42.60 m ² |
| Water capacity excl water heater (approx. 1 head / 2 head version) | 320 / 440 l |
| Fuel tank capacity (approx.) | 160 L |
| Holding tank (see option's list) | 40 l / 80 l |
| Engine battery | 75 Ah |
| Service battery (standard version) | 100 Ah |
| Main means of propulsion | Sails |
| Max. Engine power | 30 kW |

Note :

The maximum capacity of all reservoirs (like water or fuel) can only be reached in theory. Load and stability of the boat have influence on the capacity in practice. Especially for the fuel tank a reserve of 20 % is recommended.

III. ELECTRICAL SYSTEMS

A. SAFETY AND OPERATING INSTRUCTIONS FOR THE ELECTRICAL SYSTEM

WARNING

Always:

- Check the condition of the batteries (charge and electrolyte level) and the charging system before putting to sea
- Disconnect and remove batteries for winterisation
- Do not let battery voltage drop below 10,5V during winter storage.
- Carry spare lamps for all navigation lights and interior lighting. Respect power ratings, particularly for navigation lights.
- Check operation of the navigational instruments
- Check operation of navigation lights before night sailing

Never:

- Work on an electrical installation that is live.
- Make any modification to an installation and the relevant diagrams, unless it is carried out by an electrician qualified in marine electrics.
- Change or modify the breaking capacity of overload protection devices
- Replace electrical apparatus or equipment with units exceeding the rated capacity without upgrading wiring and protection.
- Leave the boat unattended when the electrical installation is powered, with the exception when applicable of the automatic bilge pump and the fire or theft protection circuit.

If a fuse or circuit-breaker blows continually, a specialist must be consulted to determine the origin of the short-circuit.

B. INSTALLING NEW EQUIPMENT

Since the 1st January 1996, electrical equipment is subject to the European "electromagnetic compatibility" directive (Ref 89/336/CEE). Hence it is necessary to install new equipment meeting this standard and bearing the CE mark. Equipment must also be supplied with a compliance certificate and instructions for use.

In the case of 220 or 110 V installations, use only double-insulated or earthed equipment. When such equipment is being installed, respect the fitting instructions (conductor size, protection).

To avoid maintenance problems, be sure to mark in the manual and modifications that may be made to the electrical diagram.

C. BATTERIES

The battery capacity has been designed to meet the power requirements of the on-board accessories. To avoid any problems, it is necessary to keep a close eye on the maintenance and correct charging of the batteries.

WARNING

- When installing new electrical appliances, take care that the overall consumption of these appliances remains within the capacity of your batteries.
- Always disconnect the -ve battery terminal before the +ve terminal
- Never allow a conductive object (tools, etc) to bridge the two battery terminals.
- When handling batteries, keep them horizontal to avoid spillage of electrolyte. Wear gloves and protective clothing that will prevent any risk of contact with electrolyte in the event of a leak.
- In the event of electrolyte splashes, rinse the affected part of the body copiously and consult a doctor.

D. ELECTRIC WINCH

WARNING

It is essential to run the engine with the throttle slightly opened when using the electric winch.

E. 220/110 VOLT INSTALLATION

Your boat is not supplied with a shore/boat supply cable or a male plug for the shore outlet. The cable must be suitable for outdoor use. Its cross-sectional area must be adjusted according to its length and the rating of the main circuit-breaker (see electrical diagram). The plug must be suitable for the female socket on the shore (if necessary, seek the advice of a professional)It should be as near as possible to the **IP 67 / IEC529** type

Disconnect current supply when the system is not being used.

Make sure all elec. appliances are earthed when necessary. Earthing is yellow or yellow/green

Only use appliances with double isolation or earthing

- Disconnect the shore/boat supply cable at the shore outlet before disconnecting it at the boat end

WARNING

To avoid electric shocks or fire :

- Switch off the shore supply at the on-board isolator before connecting or disconnecting the shore/boat supply cable.
- Connect the shore/boat supply cable at the boat end before connecting it to the shore outlet
- Disconnect the shore/boat supply cable at the shore outlet before disconnecting it at the boat end
- Close the shore outlet cover properly
- Do not modify the shore supply cable socket. Only use compatible plugs.

WARNING

Prevent shore power supply cable ends from falling in the water. An electric field may put in danger swimmers in the neighbourhood.

IV. GAS INSTALLATION

A. OPERATION ADVICE

- Read the instructions for the cooker and regulator carefully.
- Ensure that the gas cylinder and regulator are in accordance with the requirements of the cooker (flow rate, pressure, type of gas) and that the gas cylinder complies with the regulations in force in the country where it is being used.
- Shut off all appliance valves before opening the bottle valve.

WARNING !

Appliances burning fuel use up the oxygen in the cabin and release combustion products into the boat. Ventilation is required when appliances are alight. Open the coach roof ports while you are cooking.

- Do not use the oven as a heater.
- Do not obstruct quick access to the elements of the gas installation. (cylinder locker, shut-off valve).
- The gas cylinder must always be stowed in the space provided, even spare or empty ones. Keep other equipment away from this locker.

WARNING !

Never leave the boat unattended when gas appliances are alight.

- Close all valves in the circuit when the boat is left empty (shut-off valve, regulator valve), even if the cylinder is considered to be empty.
- After the boat has been shut up, never smoke when going below, and ensure that there is no smell of gas.
- If you smell gas, close the circuit valves and the cooker taps, ventilate the boat, and examine the leak's source. Do not start using the installation as long as the source has not been found and repaired.

WARNING

In the event of an emergency, the circuit valves must be closed immediately.

B. CHECKING THE SYSTEM

The gas system must be tested periodically:

- °Close all the cooker taps.
- °Open the cooker supply and regulator valves.
- °Check all connections are gas-tight using a leak detector or by applying soapy water.

| |
|---|
| WARNING ! |
| Do not use solutions containing ammonia |

| |
|---|
| DANGER ! |
| Never use a naked light to look for leaks |

Repairs and modifications to the system should be carried out by a qualified person.

Flexible hoses must be:

- checked regularly, at least once a year,
- replaced if the expiry date marked on the hose is passed,
- replaced five years after the date of manufacture that may be marked on them,
- replaced in the event of deterioration.

C. CHANGING THE GAS CYLINDER

| |
|---|
| WARNING ! |
| - Close both the cooker taps and the one in front of the cooker - Do not smoke nor use a naked light during replacement of the gas cylinder. |

V. DRAIN AND SANITATION SYSTEM

A. SPECIFICATIONS OF THE DRAIN SYSTEM

| Pump type | Theoretical flow rate |
|-----------|--------------------------|
| Manuel | 40.5 l / 45 strokes/min. |
| Electric | 900 l / h |

Read carefully the operating and maintenance instructions for the bilge pump that goes with your boat.

WARNING !

- Ensure that bilge pumps are in working order before putting to sea.
- Know where to find the hand pump and its handle.
- Know where to find the switch for the electric pump on the electrical panel
- Clean the well and pump filters regularly.
- The bilge pump system is not intended to keep the boat afloat in the event of damage. It is intended to remove water coming from spray, leaks from seacocks or any other moderate leaks.

B. PRESSURISED FRESH WATER PUMP

Fresh water is supplied to the sink and wash basins by an electric pump. A filter is installed upstream of the pump, and must be cleaned regularly.

Never allow the pump to run if the tank is empty. Change over to the other tank or fill up.


Hot water is produced by a water-heater connected to the engine cooling circuit and the shore electric supply.

After the water-heater has been emptied, make sure that the element is covered before power is re-applied.

C. SEACOCKS

Seacocks are of the 1/4-turn type:

- OPEN position: handle in line with seacock body,
- CLOSED position: handle perpendicular to seacock body.



WARNING !

- Never interfere with the tightening of the sea cocks to the hull. In the event of a leak, consult a professional.
- In bad weather or when leaving your boat, close all the sanitation system seacocks.
- Keep seacocks closed when not being used.
- During winterisation, clean and rinse the seacocks and skin fittings. Inspect the brass accessories, slight surface corrosion, consult your dealer.
- In the event of more serious corrosion, consult your dealer.

D. OPERATING THE SEA TOILETS

- Open the sea water inlet seacock.
- Open the bowl emptying seacock.
- Set the lever to the "FLUSH" position.
- Operate the pump.
- To empty the bowl and avoid any water slopping when heeling, set the lever to the "DRY BOWL" position.
- Operate the pump until the bowl is dry.
- Repeat these flushing / emptying operations as many times as is necessary to ensure complete emptying of the pipes.
- When toilets are not being used, set the lever to the "DRY BOWL" position, or the "CLEF" position for certain models.
- **Close seacocks after use, as the toilet is below the waterline**
- Change the toilet seals regularly

VI. FLOODING

Boat flooding risks:

- Before putting to sea, always check that portholes, deck hatches and any other openings that could allow flooding are shut.
- When under sail, close all seacocks, except the engine water intake.
- Periodically check:
 - Skin fittings, seacocks and pipes are watertight
 - Proper emptying of the cockpit drains.
 - Watertightness of the stern gland.

WARNING !

Cockpit locker lids must be fastened before putting to sea. This is particularly important for the lockers representing a major flooding risk

VII. FIRE PROTECTION

A. INSTALLATION

- Fire extinguishers are subject to national regulations, for this reason they are not supplied with your boat.
 - We recommend you to equip your boat with fire extinguishers meeting the ISO 9094-1 standard, with the following specifications:
 - a) Minimum capacity per extinguisher: 5A/34B,
 - b) Minimum combined extinguisher capacity: 10A/68B,
 - c) 1 extinguisher within:
 - 1 m (for boats < 10 m) or 2 m (for boats > 10 m) of the cockpit
 - 2 m of the extinguisher opening for dowsing the engine,
 - d) 1 extinguisher within 2 m of the cooker,
 - e) 1 extinguisher within 5 m of the bunks.
 - f) CO2 extinguishers may be placed in accommodation areas only where inflammable liquids are present (e.g. galley) or where there is powered electrical equipment. There must not be more than one CO2 extinguisher per area at risk, and its maximum capacity must not exceed 2 kg.
- Only compatible replacement parts must be used in fire protection systems. They must bear the same markings and be technically equivalent.

A safety cloth must be stowed in the galley in the neighbourhood of the cooker to help extinguish fire in emergency cases.

B. SAFETY INSTRUCTIONS

WARNING

It is the responsibility of the owner/ captain to :

- have fire extinguishing equipment checked in accordance with the stipulations of the builder and the regulations in your country.
- Replace fire extinguishing equipment if it has expired or been discharged, by extinguishers of equal or greater capacity.
- Show members of the crew :
 - The location and operation of fire extinguishing equipment on board
 - The location of the engine compartment extinguishing hole (located on the companionway)
- Ensure that fire extinguishing equipment is readily accessible whenever the boat is occupied.

NEVER:

- Obstruct gangways to emergency exits (deck hatches)
- Obstruct safety controls (gas valves, fuel valves, electrical switches)
- Obstruct fire extinguisher storages.
- Leave the boat unattended with a cooker or heater alight.
- Use a gas lamp in the boats
- Fill a fuel tank or change a gas cylinder while the engine is running, or the cooker or heater are alight.
- Smoke while handling fuel or gas.
- Fit fee-hanging curtains near the cooker or any other appliance with an open flame.
- Store inflammable products in the engine compartment.
- Always keep the bilges clean and check that there is no fuel vapour or gas.

WARNING

- If a CO₂ extinguisher is fitted, the following information must be displayed close to its location :
« This extinguisher contains CO₂ – use only on electrical or cooker fires. To avoid suffocation after discharging, leave the area immediately. Ventilate before re-entering.»
- Do not open the engine compartment immediately after putting out a fire, to avoid the release of toxic smoke or spraying of burning materials (oil, water).

VIII. ENGINE

Regular maintenance must be carried out in accordance with the engineer's recommendations.

Read carefully the engine operating instructions that come with the boat. Do not hesitate to consult your agent or a qualified professional.

A. GENERAL PRECAUTIONS

WARNING

Ensure

- Ensure that the cooling circuit water intake seacock is open, and that water is coming out of the engine exhaust.
- Boats fitted with rotating seal stern gland : bleed the air from the gland after each launch.
- Do not obstruct engine vents.
- Avoid contact between inflammable materials and hot engine part

Regularly check the condition of the anodes and ensure that they are suitable for the boat's environment (fresh water, salt water).

Any engine change must respect the capacities of the boat and be performed by an engineer specializing in marine mechanics.

B. EXHAUST GAS EMISSION

WARNING !

Internal combustion engines produce carbon monoxide. Prolonged exposure to exhaust gasses can have serious consequences, and may even cause death.

C. SAFETY

DANGER !

- In order to avoid all risk of serious injury from the propeller, the engine must not be started when there are swimmers near the boat.
- Whenever possible, the engine must be stopped for any engine maintenance or checking operations. If not, special attention must be paid to moving items (belts, etc...) in order to avoid any risk of injury.
- Do not combine sailing and using engine power if the boat is heeling more than 10 %

D. WINTERISATION

In particular, follow the instructions for winterisation.

In the absence of other instructions, proceed as follows:

- Close the engine water intake seacock,
- Disconnect the pipe from the engine water intake seacock,
- Drain the sea-water circuit,
- Place the pipe into a drum of -25° anti-freeze coolant,
- Run the engine until the fluid comes out of the exhaust,
- At the end of this operation, re-connect the pipe to the seacock,
- Attach a notice to the electrical panel and the battery isolator to the effect that the engine water intake seacock is closed.

IX. FUEL INSTALLATION

Flexible fuel pipes must be:

- replaced by pipes bearing the same markings
- replaced in the event of deterioration.

WARNING !

- Depending on the trim and loading of your boat, the whole of the nominal fuel capacity may not be usable. Always maintain a 20 % reserve for safety.

Never:

- Store inflammable materials in unventilated spaces
- Smoke while filling tanks
- Obstruct ventilation openings (vents, engine ventilation grills)
- Modify the installation, unless this is carried out by a technician qualified in this field.

X. STEERING SYSTEM

The steering system plays a vital role in the safety and comfort of your boat.

A. STEERING WHEELS

The **Dufour 385** is fitted with a double wheel and a system of rudder cables and chains.

Periodic checks to be performed:

- Check the play in the various components (rudder stock/bearings, rudder cable tension and wear). In the event of doubt or a problem, consult your agent.

B. EMERGENCY TILLER

WARNING

- The **Dufour 385** is equipped with an emergency tiller that must be kept readily accessible, we advise you to stow it in a cockpit locker near the tiller deck plate.
- It is only designed for sailing at reduced speed in the event of damage to the helm.

How to install:

- Unscrew the tiller deck plate cover located in the cockpit floor,
- Fit the tiller onto the head of the rudder stock.

XI. SAILING

WARNING

- Under all circumstances, suit the speed of your boat to the surrounding conditions and always maintain a safety margin. Pay particular attention to :
 - The state of the sea, currents, the strength of the wind
 - Other boat movements
 - Manoeuvres in port
 - When passing through mooring areas
- Obey the rules of priority as defined in the rules of the road and imposed by the COLREG.
- Ensure that you always leave enough room for stopping or manoeuvring if necessary to avoid a collision.
- Respect speed limit zones
- Out of courtesy and for the safety of other boats, take care not to create a large wash.

WARNING

- You must fit your boat with grab lines. Fixing points are provided on the deck. Refer to the boat's deck fittings drawings.
- The stability of your boat was designed taking into account the shipyard catalogue options. Any alteration to on-board weight distribution (for example : adding a radar, changing the engine, etc...) can affect the stability, trim and performance of your boat.
- Towing a boat causes a significant extra strain that will have an unfavourable effect on the stability of your boat.
- **Never :**
 - Use the boom to lift heavy weights.

XII. LIGHTNING PROTECTION

Your boat is protected against lightning. The rigging is electrically connected to earth. Nonetheless, for your safety, it is necessary to respect certain precautions.

A. MAINTENANCE

If the boat has been struck by lightning:

- the protection installation must be inspected to detect physical damage and check the integrity of the device, as well as the continuity of the earthing.
- the compasses, electrical and electronic devices must be examined in order to ascertain if damage or calibration changes have occurred.

B. PROTECTION OF PEOPLE DURING A THUNDERSTORM

WARNING

During a thunderstorm, it is preferable to obey the following instructions :

- People should stay below as far as possible.
- People should stay out of the water and not let their arms or legs hang into the water.
- Whilst maintaining satisfactory control of the boat and its sailing, people should not touch any part connected to a lightning protection installation, especially not in such a way as to form a link between such parts.
- It is desirable that people should avoid any contact with metal parts of the rigging, the spars, deck fittings and the lifelines.

XIII. ENVIRONMENTAL PROTECTION and SAFETY

We recommend keeping yourself informed about local regulations concerning respect for the environment, and to obey international regulations against pollution in the marine environment (MARPOL) as well as codes of good practice.

WARNING !

- Most cleaning products, engine oils and hydrocarbons are likely to affect the environment, so they should be discharged in authorized locations (check with the Harbour Master's Office).
- Certain products can likewise represent a risk for your own and others' safety, which is why it is important to read and obey the instructions for use.
- Substances used must be labelled and stored in an appropriate, ventilated place in the boat.

XIV. SAFETY EQUIPMENT

There is no harmonization of obligatory safety equipment across the European Community. You should seek information about national requirements for CE-marked boats.

In France, yachts bearing the CE mark must carry the facilities and safety equipment stipulated for the category of sailing chosen by the yachtsman within the following limits:

| Design Category | Possible sailing categories |
|-----------------|-----------------------------|
| A | 1.2.3.4.5.6 |
| B | 2.3.4.5.6 |
| C | 4.5.6 |
| D | 6 |

If your boat is equipped with a life-raft, read its instruction manual carefully. The crew should be familiarized with the use of all safety equipment (harnesses, flares, life-raft, etc...). Training sessions are organized regularly by sailing schools and clubs.

XV. HANDLING, TRANSPORTING, LIFT OUT

When craning, take care that the slings are correctly positioned and are not fouling the propeller, the saildrive or a fragile sensor.

Lifting frames should be wide enough, or fitted with spreaders to avoid exerting excessive lateral pressure on the rubbing band.


Avoid letting slings foul the lifelines. During transport or lift out, the keel should be in proper contact with its support, and should be taking most of the boat's weight.

Cradle pads must be positioned against structural elements and exert only the pressure necessary for the boat's good balance.

Whenever the boat is out of the water, use the opportunity to inspect the propeller, rudder, skin fittings and sensors.

WARNING !

The lifting point is situated close to the sail-drive




△ **Lifting point**

**PLANS
DUFOUR 385**

| | |
|---|----|
| <i>I. Presentation plan</i> | 26 |
| <i>II. Interior layout plans</i> | 27 |
| <i>III. Deck fittings plan</i> | 28 |
| <i>IV. Sail plan</i> | 30 |
| <i>V. Halyard and sheet rigging plan</i> | 32 |
| <i>VI. 110 V circuit diagram</i> | 34 |
| <i>VII. 220 V circuit diagram</i> | 36 |
| <i>VIII. Charging and power circuit diagram</i> | 38 |
| <i>IX. 12v / 220 v electric switch panel diagram</i> | 40 |
| <i>X. Electric panel terminal diagram</i> | 42 |
| <i>XI. 12 V installation drawing</i> | 44 |
| <i>XII. 220 V installation drawing</i> | 46 |
| <i>XIII. Steering wheel drawing</i> | 48 |
| <i>XIV. Gas circuit diagram</i> | 50 |
| <i>XV. Abandon ship plan</i> | 52 |
| <i>XVI. Fresh water circuit diagram</i> | 54 |
| <i>XVII. Drain system diagram</i> | 56 |
| <i>XVIII. Skin fitting location drawing</i> | 58 |
| <i>XIX. Engine installation drawing</i> | 60 |
| <i>XX. Holding tank fitting drawing</i> | 62 |
| <i>XXI. Holding tank fitting drawing in 3 cabin version</i> | 64 |

I. Presentation plan



II. Interior layout plans

15-03-04




Fig. A




Fig. B




Fig. C

| AMENAGEMENT | |
|-------------|----------------------------|
| fig.A | 3 cabin + 2 toilet version |
| fig.B | 3 cabin + 1 toilet version |
| fig.C | 2 cabin + 1 toilet version |




Dufour 385 **2**

III. Deck fittings plan

| Rep. | Description | Number |
|------|---|--------|
| 1 | Bow fitting | 1 |
| 2 | Forestay chainplate | 1 |
| 3 | Rubbing plate | 1 |
| 4 | Port pulpit | 1 |
| 5 | Starboard pulpit | 1 |
| 6 | Bow protection plate * | 1 |
| 7 | Electric windlass * | 1 |
| 8 | Removable inner forestay chainplate * | 1 |
| 9 | Roller furling guide block on stanchion | 1 |
| 10 | Stanchion | 8 |
| 11 | Stanchion base | 14 |
| 12 | Sheet lead for roller furling system | 4 |
| 13 | Gooseneck at mast step | 1 |
| 14 | Mast step base | 1 |
| 15 | Shroud chainplate | 2 |
| 16 | 4 wheel turning block | 1 |
| 17 | Toe rail in aluminium | 1 |
| 18 | Fairlead amidships | 2 |
| 19 | 3 wheel turning block * | 1 |
| 20 | Mooring cleat | 6 |
| 21 | Genoa track + car + end fittings | 2 |
| 22 | Double cleat * | 1 |
| 23 | Mainsail track, complete | 1 |
| 24 | Vertical turning block | 2 |
| 25 | Triple cleat | 1 |
| 26 | Single cleat | 1 |
| 27 | Clam cleat | 2 |
| 28 | Halyard winch | 1 |
| 29 | Jamming cheek block | 2 |
| 30 | Folding pad eye | 1 |
| 31 | Single cleat | 1 |
| 32 | Sheet winch | 2 |
| 33 | Port pushpit | 1 |
| 34 | Starboard pushpit | 1 |
| 35 | Aft port fairlead | 1 |
| 36 | Aft starboard fairlead | 1 |
| 37 | Optional winch * | 1 |
| 38 | Hinges for helmsman seat | 2 |
| 39 | Bathing ladder | 1 |
| 40 | Back stay chainplate | 2 |
| 41 | Folding pad eye * | 2 |


| Rep. | Description | Number |
|------|---|--------|
| 42 | Winch handle holder | 2 |
| 43 | Reinforced stanchion for life line gate* | 4 |
| 44 | Folding pad eye * | 1 |
| 45 | Support for bowsprit pole * | 1 |
| 46 | Folding pad eye * | 1 |
| 47 | Deck vent | 2 |
| 48 | Dorade box + protection * | 2 |
| 51 | Deck hatch T44 | 2 |
| 52 | Deck hatch T20 | 1 |
| 53 | Roof portlight T4 | 6 |
| 54 | Deck hatch T00 | 2 |
| 55 | Cockpit portlight T1 * | 2 |
| 56 | Hull portlight | 2 |
| 57 | Sliding hatch | 1 |
| 58 | Companion way access panel | 1 |
| A | Life line fixing points (on port and starboard mooring cleat) | |
| B | Towing point (Port and starboard) | |
| C | Portlights that must be shut while Navigating | |
| D | « Man overboard » safety ladder | |
| E | Storage space for life raft | |
| F | Fixing points for life belt | |
| G | Storage locker that must be shut while Navigating | |

* Option



IV. Sail plan

| | |
|------------------|---------------------|
| I | 14.025 m |
| J | 4.39 m |
| P | 12.80 m |
| E | 4.25 m |
| LP | 6.15 m |
| Genoa surface | 42.6 m ² |
| Mainsail surface | 31.5 m ² |







Dufour 385 (4)

V. Halyard and sheet rigging plan

| <i>Rep.</i> | <i>Description classic mast</i> | |
|-------------|---|---|
| 1 | Single block + swivel shackle | 4 |
| 2 | Fiddle block | 1 |
| 3 | Mainsail sheet - Ø12 - white/red | 1 |
| 4 | Fiddle block + cleat | 1 |
| 5 | Fiddle block | 1 |
| 6 | Boom downhaul - Ø12 - white/red | 1 |
| 7 | Rigid boom vang * | 1 |
| 8 | Mainsail halyard - white/red | 1 |
| 9 | Adjusting line mainsail track car - white/red | 2 |
| 10 | Reef no. 1 – white/blue | 1 |
| 11 | Reef no. 2 - white/green | 1 |
| 12 | Genoa roller furling line - white/blue | 1 |
| 13 | Genoa sheet - Ø14 - white/blue | 2 |
| 14 | Genoa halyard – white/blue | 1 |
| 15 | Spinnaker halyard -Ø12 - white/yellow * | 1 |
| 16 | Single block + swivel shackle * | 2 |
| 17 | Spinnaker sheet – Ø12 – white/yellow * | 2 |
| 18 | Removable inner forestay halyard Ø12 - white/green * | 1 |
| 19 | | |

* Option




VI. 110 V circuit diagram

| <i>Rep.</i> | <i>Description</i> |
|-----------------------------|----------------------------------|
| <i>Equipment</i> | |
| A | Shore power connection* |
| B | Electric box with main switch * |
| C | Electric box with differential * |
| D | Battery charger* |
| E | Connecting box* |
| F | Water heater |
| G | 110V - 60Hz socket* |
| <i>Cable Colours</i> | |
| <i>b</i> | Light blue |
| <i>g</i> | Green |
| <i>m</i> | Brown |
| <i>n</i> | Black |
| <i>r</i> | Red |
| <i>v</i> | Green yellow |
| <i>w</i> | White |

* Option


** Not supplied



VII. 220 V circuit diagram


| <i>Rep.</i> | <i>Description</i> |
|-----------------------------|----------------------------------|
| <i>Equipment</i> | |
| A | Shore power connection * |
| B | Electric box with main switch * |
| C | Electric box with differential * |
| D | Battery charger* |
| E | Connecting box * |
| F | Water heater |
| G | 220V sockets* |
| <i>Cable colours</i> | |
| <i>b</i> | Light blue |
| <i>g</i> | Green |
| <i>m</i> | Brown |
| <i>n</i> | Black |
| <i>r</i> | Red |
| <i>v</i> | Green yellow |
| <i>w</i> | White |

* Option




VIII. Charging and power circuit diagram

| <i>Rep.</i> | <i>Description</i> |
|-------------|--|
| A | Electric windlass* |
| B | Remote control for windlass * |
| C | Relay for windlass remote control * |
| D | Electric panel with terminals |
| E | Battery charger* |
| F | 12V switch panel |
| G | 80 Amp unipolar circuit breaker for windlass * |
| H | Service batteries (2 as standard) (3*) |
| I | Fuse 125A |
| J | Service battery switch |
| K | Fuse 5A* |
| L | Alternator |
| M | Current distributor |
| N | Starter |
| O | Engine battery |
| P | Engine battery switch |
| Q | Windlass relay* |
| B- | Connection – chart table |
| B+ | Connection + chart table |
| R | Fuse 5A for engine compartment ventilator |
| S | Relay for ventilator |
| T | Electric ventilator |
| Z- | Connection – engine compartment |
| * | Option |



IX. 12v / 220 v electric switch panel diagram


| <i>Rep.</i> | <i>Description</i> | <i>Security level</i> |
|-------------|------------------------------|-----------------------|
| 1 | Navigation light | 6A |
| 2 | Steaming light | 6A |
| 3 | Anchor light | 6A |
| 4 | Refrigerator | 10A |
| 5 | Saloon lights | 16A |
| 6 | Cabin lights | 16A |
| 7 | Water circuit | 10A |
| 8 | Bilge pump | 16A |
| 9 | Shower water evacuation pump | 10A |
| 10 | Navigation instruments | 10A |
| 11 | Autopilot | 20A |
| 12 | 12V socket – HiFi | 10A |



X. Electric panel terminal diagram

| <i>Rep.</i> | <i>Description</i> |
|-----------------------------|---|
| - | Battery negative pole |
| + | Battery positive pole |
| C1 | Navigation lights and compass |
| C2 | Steaming light |
| C3 | Anchor light |
| C4 | Relay for refrigerator thermostat |
| C5 | Saloon lights |
| C6 | Cabin and toilet cabin lights |
| C7 | Water circuit |
| C8 | Bilge pump |
| C9 | Shower water evacuation pump |
| C10 | Navigation instruments* And reading light at chart table |
| C11 | Autopilot * |
| C12 | 12V socket and HiFi * |
| T1 | Battery engine test |
| G1 | Tank level indicator G0 |
| B+ | Light bulb + chart table |
| B- | Light bulb – chart table |
| Z- | Light bulb – engine compartment |
| <i>Cable colours</i> | |
| <i>n</i> | Black |
| <i>r</i> | Red |
| <i>w</i> | White |
| <i>o</i> | Orange |
| <i>m</i> | Brown |
| <i>b</i> | Blue |


* Option



XI. 12 V installation drawing

| <i>Rep.</i> | <i>Description</i> |
|-------------|--------------------------------|
| 1 | Port light |
| 2 | Starboard light |
| 3 | Windlass * |
| | Relay for windlass * |
| 4 | Adjustable spot light |
| 5 | Ceiling and interior light |
| 6 | Ceiling light toilet +interior |
| 7 | Bulkhead mounted light |
| 8 | Loudspeaker HiFi/radio CD * |
| 9 | |
| 10 | Chart table reading light |
| 11 | 12V switch panel |
| 12 | 12V socket |
| 13 | Cooling circuit |
| 14 | Shower water evacuation pump |
| 15 | Bilge pump |
| 16 | Engine starting battery |
| 17 | General circuit breaker |
| 18 | Service battery |
| 19 | Distributor |
| 20 | Water circuit |
| 21 | Bilge ventilator |
| 22 | Battery charger* |
| 23 | Compass |
| 24 | Navigation instruments * |
| 25 | Stern light |
| 26 | Steaming light |
| 27 | Anchor light |
| 28 | Battery switches |
| 29 | Fuel gauge |
| 30 | Autopilot engine * |
| 31 | Speed and depth sounders * |


* Option



XII. 220 V installation drawing

| <i>Rep.</i> | <i>Description</i> |
|-------------|---------------------------|
| 1 | 220V socket (or 110V)* |
| 2 | Water heater |
| 3 | Battery charger * |
| 4 | General circuit breaker * |
| 5 | Shore power connection * |
| 6 | Electric box * |





* Option



XIII. Steering wheel drawing

| Rep. | Description |
|-------------|------------------------------|
| 1 | Emergency tiller |
| 2 | Steering wheel (2) |
| 3 | Compass |
| 4 | Rudder stock stop |
| 5 | Rudder stock spindle |
| 6 | Rudder + stock |
| 7 | Bush |
| 8 | Nylon O-ring |
| | Higher and lower rudder |
| 9 | bearings |
| 10 | Rudder stock shaft |
| 11 | Grab rail on console |
| 12 | Autopilot chain * |
| 13 | Autopilot engine * |
| 14 | Autopilot sprocket * |
| 15 | Backing plate |
| 16 | Square |
| 17 | Sheath end |
| 18 | Sheath |
| 19 | Chain set 5/8P |
| 20 | Cable Ø5 |
| 21 | Quadrant |
| 22 | Bulckhead instrument |
| 23 | Bulckhead instrument + brake |



* Option



XIV. Gas circuit diagram

| <i>Rep.</i> | <i>Désignation</i> |
|-------------|-------------------------------------|
| 1 | Gas cylinder ** |
| 2 | Gas cylinder valve ** |
| 3 | Expander ** |
| 4 | Connecting piece |
| 5 | Connection / size 6x8 |
| 6 | Watertight through bulkhead fitting |
| 7 | Plastic piping |
| 8 | Copper conduit 6x8 |
| 9 | CE gas tap (under the cooker/oven) |
| 10 | Long connecting pipe |
| 11 | 2 burner cooker and oven |


** Not supplied



XV. Abandon ship plan


| <i>Rep.</i> | <i>Description</i> |
|-------------|---|
| EXIT | Emergency exit |
| Ex | Recommended space for extinguishers |
| 1 | Under chart table ** |
| 2 | Under saloon bench ** |
| Wh | Access hole to engine compartment For extinguisher |

** Not supplied




XVI. Fresh water circuit diagram

| <i>Rep.</i> | <i>Description</i> |
|-------------|--|
| 1 | Deck filler |
| 2 | Water infill |
| 3 | Vent |
| 4 | Ventilation piping |
| 5 | Front water tank |
| 6 | Cold water piping |
| 7 | 2 way collector |
| 8 | Shower mixing tap |
| 9 | Pressurised water circuit |
| 10 | Sweet water filter |
| | Piping for hot water heat exchange through |
| 11 | engine |
| 12 | water heater |
| 13 | Galley mixing tap |
| 14 | Deck shower |
| 15 | Aft water tank |
| 16 | Hot water piping |



XVII. Drain system diagram


| <i>Rep.</i> | <i>Description</i> |
|-------------|-----------------------------------|
| | <i>Electric bilge pump</i> |
| 1 | Strainer |
| 2 | Evacuation piping Ø20 |
| 3 | Electric bilge pump |
| 4 | Deck outlet |
| | <i>Manual bilge pump</i> |
| 5 | Strainer |
| 6 | Evacuation piping Ø25 |
| 7 | Manual bilge pump |
| 8 | Deck outlet |



XVIII. Skin fitting location drawing



| <i>Rep.</i> | <i>Function</i> | <i>Ø</i> |
|---------------------------------|--------------------------------------|----------|
| <i>Skin fittings and valves</i> | | |
| 1 | Galley sink evacuation | 1" |
| 2 | Wash basin evacuation | 1" |
| 3 | Toilet infill | 3/4" |
| 4 | Toilet outlet | 1"1/4" |
| 5 | Holding tank outlet* | 2" |
| 6 | Water foot pump infill * | 1/2" |
| 7 | Shower water evacuation | 3/4" |
| <i>Skin fittings</i> | | |
| 8 | Water evacuation electric bilge pump | 3/4" |
| 9 | Water evacuation manual bilge pump | 1" |

* Option




XIX. Engine installation drawing

| Rep. | Description |
|-------------|---|
| | General |
| 1 | Engine |
| 2 | Saildrive |
| 3 | Sea water pump for engine |
| 4 | Engine base in polyester |
| 5 | Engine control panel |
| 6 | Propeller |
| 7 | Anode |
| | Cooling circuit / Exhaust system |
| 8 | Sea water valve |
| 9 | Sea water piping |
| 10 | Sea water filter |
| 11 | Anti-siphon valve |
| 12 | Waterlock |
| 13 | Exhaust piping |
| 14 | Exhaust outlet |
| | Fuel circuit |
| 15 | Deck filler for fuel |
| 16 | Fuel infill |
| 17 | Fuel tank vent |
| 18 | Ventilation piping for fuel tank |
| 19 | Fuel tank |
| 20 | Emergency fuel shut-off handle |
| 21 | Fuel supply piping |
| 22 | Fuel return piping |
| 23 | Fuel filter |
| | Ventilation |
| 24 | Ventilation piping |
| 25 | Bilge ventilator |
| 26 | Ventilation grills |
| | Various |
| 27 | Engine starting battery |
| 28 | Engine command |
| 29 | Engine command cables |
| 30 | Circuit breakers |



XX. Holding tank fitting drawing

| <i>Rep.</i> | <i>Description</i> |
|-------------|--------------------------------|
| | 2 cabin version |
| 1 | Skin fitting & valve 3/4" |
| 2 | Skin fitting & valve 1" 1/4 |
| 3 | Skin fitting & valve 2" * |
| 4 | Piping Ø20 |
| 5 | Anti odour piping Ø38 * |
| 6 | Anti odour piping Ø51 * |
| 7 | 3 way valve in plastic Ø38 * |
| 8 | Holding tank in polyethylene * |
| 9 | Deck outlet in aluminium Ø50 * |
| 10 | Vent in brass * |
| ⓧ | Gooseneck |
| | * Optional equipment |
| | * Supplied as standard |



XXI. Holding tank fitting drawing in 3 cabin version

| <i>Rep.</i> | <i>Description</i> |
|-------------|-------------------------------------|
| | 3 cabin version |
| 1 | Through hull fitting & valve 3/4" |
| 2 | Through hull fitting & valve 1" 1/4 |
| 3 | |
| 4 | Piping Ø20 |
| 5 | Anti odour piping Ø38 * |
| 6 | Anti odour piping Ø51 * |
| | 3 way valve in plastic PVC Ø38 |
| 7 | * |
| 8 | Holding tank in polyethylene * |
| 9 | Deck outlet in aluminium Ø50 * |
| 10 | Vent in brass * |
| 11 | Manual evacuation pump * |
| 12 | Deck outlet in aluminium Ø38 * |
| 13 | Piping Ø25 |
| (x) | Gooseneck |
| | * Optional equipment |
| * | Supplied as standard |

